Customized displays and seamless integration

Advanced machine information

The **RMQ-Titan Advanced Indicator** delivers clear, intuitive visual guidance to communicate machine status, process stages, and operational progress. It offers comprehensive customization capabilities, enabling users to create up to 24 tailored visual displays that incorporate a wide range of colors, text, graphics, and sensor data, all through an intuitive configuration tool. It is designed to fit a standard 22.5 mm mounting hole, consistent with our RMQ-Titan M22 pushbuttons, allowing for efficient installation on control cabinet doors, enclosures, or machinery, and ensuring a uniform appearance and user experience. The IP66 and IP69 protection ratings ensure reliable performance in diverse environments.

Reliable data flow for reduced downtime

The RMQ-Titan Advanced Indicator helps operators monitor performance, optimize uptime, and reduce maintenance time for their machines.

F·T·N

Powering Business Worldwide

Suitable for many applications

The RMQ-Titan Advanced Indicator delivers decentralized status notifications for complex machinery on the shop floor, facilitating faster maintenance interventions, minimizing troubleshooting time, and improving machine utilization.

Furthermore, it is well-suited to low-complexity machines that do not incorporate PLCs.

The Advanced Indicator is also highly effective for specialised outdoor vehicles, such as those used for asphalt repair or sewer maintenance, by supplying operators with critical operational data outside the vehicle cabin.

Additionally, it supports auxiliary equipment including cooling, mixing, and packaging units, by displaying essential information such as temperature, pressure, and error alerts.

Product Overview

Description	Model code (Article number)
RMQ-Titan Advanced Indicator • Display, 2" TFT, 22.5 mm mounting hole, IP66, IP69, UL 508 Type 3R, 4X, 12, 13 • Control module Hardwired, 6 digital input + 2 configurable input (digital / 0-10V / 0-20mA / 4-20mA) USB-C interface for configuration U_e = 12-24 V DC, IP20, -25° to +55°C	M22-AI-8I (EP-401626)
Surface mounting enclosure • IP66, IP69 • 1 mounting hole for the RMQ-Titan Advanced Indicator	M22-I1-AI (EP-401628)

Easy configuration via PC and USB-C cable

The RMQ-Titan Advanced Indicator is easy to configure with our free software and uses a USB-C cable for fast data transfer to a PC.

For more information, visit **Eaton.com/advancedindicator**

Follow us on social media to get the latest product and support information.

EATON
Powering Business Worldwide